

HR1 Headrail

17mm +

Does not include fixings		
Panel thickness	ANODISED	PPC
1.0M LENGTH 17mm +	HR1A1	HR1P1
2.0M LENGTH 17mm +	HR1A2	HR1P2
3.0M LENGTH 17mm +	HR1A3	HR1P3

1. Once the fascia's and partitions are erected the headrail can be fitted.
2. Measure the cubicle runs and ensure that any headrail joints are in the middle of fascia's and not on door openings.
3. The headrail should be fitted to the top and outside face of the fascia's.
4. Fix the headrail to the Plumb end fascia by drilling through the top of the headrail into the top of the fascia with a 3.5mm drill bit to and securing with a No.8 Wood screw of 25mm or longer.
5. Once fitted work along the cubicle run ensuring each fascia and doorway is parallel then fix in place with the headrail.

