

# L06 SUPPORT LEG

12-13mm & 17-21mm

Includes fixings for both 12-13mm & 17-21mm		
Support Height	ANODISED	PPC
20mm	L0620A	L0620P

1. Mark off the vertical centreline of the leg onto the fascia and drill the 10mm diameter hole 25mm higher than the foot step and position the leg as shown in the drawing.
2. The Leg can now be secured to the floor by using the holes as a guide and drilling the floor with a 5.5mm masonry drill, the holes need to be at least 45mm deep.
3. Push the red plug into the floor hole and secure the leg using the screws provided.
4. The partition can now be offered up to the wall mounting brackets and secured to the leg using the T-Nut and All Thread provided.

